

## 適用鏡頭

Canon EF 14mm f/2.8 L	Canon EF 11-24mm f/4 L USM	Canon EF-S 60mm f/2.8 USM
Canon EF 24mm f/1.4 L	Canon EF 16-35mm f/2.8L II	Canon EF-S 10-22mm f/3.5-4.5
Canon EF 24mm f/1.4L II USM	Canon EF 16-35mm f/2.8 L III USM	Canon EF-S 15-85mm f/3.5-5.6 IS USM
Canon EF 24mm f/2.8	Canon EF 17-40mm f/4L	Canon EF-S 18-55mm f/3.5-5.6 IS
Canon EF 28mm f/1.8	Canon EF 20-35mm f/2.8 L	Canon EF-S 18-135mm f/3.5-5.6 IS STM
Canon EF 35mm f/1.4L	Canon EF 20-35mm f/3.5-4.5 USM	Canon EF-S 18-200mm
Canon EF 40mm f/2.8 STM	Canon EF 24-70mm f/2.8L II USM	
Canon EF 50mm f/1.4 USM	Canon EF 24-70mm f/4L IS USM	SIGMA 24mm f/1.4 DG
Canon EF 50mm f/1.8 STM	Canon EF 24-85mm f/3.5-4.5 USM	SIGMA 35mm f/1.4 DG
Canon EF 50mm f/1.8 II	Canon EF 24-105mm f/3.5-4.5	SIGMA 85mm f/1.4 DG
Canon EF 50mm f/2.5	Canon EF 24-105mm f/4L IS	SIGMA 10-20mm f/4-5.6 DC
Canon EF 85mm f/1.2L II USM	Canon EF 28-80mm f/3.5-5.6 II	SIGMA 24-35mm f/2 DG
Canon EF 85mm f/1.8 USM	Canon EF 28-135mm f/3.5-5.6 IS	SIGMA 24-70mm f/2.8 DG
Canon EF 100mm f/2 L	Canon EF 70-200mm f/2.8 L	SIGMA 50-150mm f/2.8 APO DC HSM
Canon EF 100mm f/2.8 Macro	Canon EF 70-200mm f/2.8 L IS II USM	SIGMA 70-300mm f/4-5.6 DG
Canon EF 135mm f/2 L	Canon EF 70-200mm f/4 L	SIGMA 120-300mm f/2.8 DG
Canon EF 180mm f/3.5 L	Canon EF 70-200mm f/4 L IS USM	
Canon EF 200mm f/2.8 L	Canon EF 70-300mm f/4.5-5.6 DO IS USM	
Canon EF 300mm f/4L IS	Canon EF 70-300mm f/4-5.6 IS	Tamron 35mm f/1.8 DI VC USD
Canon EF 400mm f/4 DO IS USM	Canon EF 70-300mm f/4-5.6 IS II USM	Tamron AF 17-50mm f/2.8 Di-II LD Aspherical
Canon EF 400mm f/5.6 L	Canon EF 70-300mm f/4-5.6 L IS USM	Tamron SP 18-270mm f/3.5-6.3 Di-II
Canon EF 500mm f/4 L USM		Tamron SP 24-70mm f/2.8 DI VC USD G2
	YongNuo EF 35mm f/2.0	Tamron SP 150-600mm f/5-6.3
	YongNuo EF 50mm f/1.8	