

序号	兼容镜头(佳能变焦)	序号	兼容镜头(佳能定焦)
1	Canon EF 11-24mm F7.0L USM	20	Canon EF 14mm f/2.8 L
2	Canon EF 16-35mm f/2.8L II	21	Canon EF 24mm f/1.4L II USM
3	Canon EF 16-35mm f/2.8 L III USM	22	Canon EF 24mm f/2.8
4	Canon EF 17-40mm f/4	23	Canon EF 24mm f/1.4L
5	Canon EF 20-35mm f/2.8 L	24	Canon EF 28mm f/1.8
6	Canon EF 20-35mm f/3.5-4.5 USM	25	Canon EF 35mm f/1.4L
7	Canon EF 24-70mm f/4L IS USM	26	Canon EF 35mm f/2.0L
8	Canon EF 24-70mm f/2.8L II USM	27	Canon EF 40mm f/2.8 STM
9	Canon EF 24-105mm f/4L IS	28	Canon EF 50mm f/1.4 USM
10	Canon EF 24-85mm f/3.5-4.5 USM	29	Canon EF 50mm f/2.5
11	Canon EF 24-105mm f/3.5-4.5	30	Canon EF 50mm f/1.8 STM
12	Canon EF 28-80mm f/3.5-5.6 II	31	Canon EF 85mm f/1.8 USM
13	Canon EF 28-135mm f/3.5-5.6 IS //E7	32	Canon EF 85mm f/1.2L II USM
14	Canon EF 70-200mm f/2.8L IS II USM	33	Canon EF 100mm f/2.0
15	Canon EF 70-200mm f/4L	34	Canon EF 100mm f/2.8 Macro
16	Canon EF 70-300mm f/4-5.6 IS USM	35	Canon EF 135mm f/2.0L
17	Canon EF 70-300mm f/4.5-5.6 DO IS USM	36	Canon EF 180mm f/3.5L
18	Canon EF 70-200mm f/4L IS USM	37	Canon EF 200mm f/2.8L
19	Canon EF 70-300mm f/4-5.6L IS USM	38	Canon EF 300mm f/4L IS
		39	Canon EF 400mm f/4.0 DO IS USM
		40	Canon EF 400mm f/5.6L
		41	Canon EF 500mm f/4L IS USM
序号	兼容镜头(适马变焦)	序号	兼容镜头(适马定焦)
42	SIGMA 24-35mm f/2 DG	46	SIGMA 24mm f/1.4 DG
43	SIGMA 24-70mm f/2.8 DG	47	SIGMA 35mm f/1.4 DG
44	SIGMA 70-300mm f/4-5.6 DG	48	SIGMA 85mm f/1.4 DG
45	SIGMA 120-300mm f/2.8 DG		

序号	兼容镜头(腾龙 Tamron)	序号	兼容镜头(永诺 YN)
49	Tamron AF 17-50mm f/2.8 Di-II LD	54	YN EF 50mm f/1.8
50	Tamron 8-270mm f/3.5-6.3 Di II VC		
51	Tamron SP24-70mm f/2.8 Di- VC USD		
52	Tamron SP 150-600MM F/5-6.3 Di VC USD		
53	Tamron SP35MM F1.8 DI VC USD		